



# Swyft TV Gen 2 Fire TV User Guide

Swyft Fiber

The information included in this document is correct at the time of release.

© 2025 SFN, all rights reserved. Printed in the USA.

SFN TV Now is a registered trademark of SFN. All other trademarks are the property of their respective owners.

## Table of Contents

- Installing the Swyft TV App
- Introduction to Your Main TV Features
- Getting Started with the Remote Control Main Features
- Main Menu
- TV Guide
- Future Program Options in TV Guide
- Restart TV – Watch Programs That You Missed
- Program Options While Watching TV
- How to See Your 10 Last Watched Channels
- How to Record
- Settings
- Create Favorite Channel Lists
- How to See Your Favorite Channels Lists
- Changing Your Favorite Lists
- Advanced Settings to Change TV Guide View

## Installing the Swyft TV App

Make sure your Fire TV device is connected to your home internet (Wi-Fi or wired ethernet). On the Amazon Home screen, search for "**SWYFT TV**", or your IPTV provider logo. Select the version as shown below. Then install it. Log in with your username and password, then type in any device name you want. **NOTE: You must use a unique name for each Fire TV device.** Then select "Submit". If you see an error, please check that you entered the login correctly.

In a few moments, you will see the first live TV channel in the lineup.

## Introduction to Your Main TV Features

Here are some of the main features available to you.

- **Replay a program that aired up to 24 hours ago** – go back up to 24 hours ago in the TV Guide to watch or record a program
- **Pause Live TV** – you can always pause Live TV, but you have more options when you press the center circle button on your remote (including starting any program over from the beginning)
- **See the last 10 channels you watched** - while watching a program, press the center circle remote button and scroll down a few rows to display the "Last Watched" channel menu
- **Record** - what you are watching live or schedule a future recording from the TV Guide. You have 112 hours of recording space, and recordings are kept for 7 days

## Getting Started with the Remote Control Main Features

**NOTE:** There are some "long press" button features (hold button down for 2 seconds) that will be explained throughout the document.

### Main Menu

Key	Action
1	Channel Up / Down
2	Program Options while watching full screen TV
3	Vertical Channel list
4	Main Menu
5	Go Back
6	Exit to Fire TV Home Screen

## TV Guide

Two Guide views are available. The left grid style is the default view, but you can choose the right view in Settings / Advanced / Guide Type.

- In the left grid Guide version, the live TV channel is in the upper right corner, where you can pause the video. You can pause the live video in the corner while you are scrolling in the Guide.
- In the right Guide version, there is no live TV view, but you have bigger channel logos and fonts.

## Future Program Options in TV Guide

Here are the options for programs airing in the future. Selecting "Autotune" will automatically tune this program when it starts, but only if you turn Autotuning ON in the Settings menu.

## Restart TV – Watch Programs That You Missed

You can scroll back 24 hours in the TV Guide to watch or record a program you may have missed. The main Menu also has a "Restart TV" list of all the programs available to restart the past 24 hours listed by channel number.

## Program Options While Watching TV

While watching a program (live or replay), press the remote center circle button to display all your options.

- Pause Live TV
- Arrow up to the top bar to quickly rewind or fast forward
- Or use your remote buttons to pause, rewind, fast forward
- Or use the onscreen pause, rewind & fast forward icons (these icons rewind & fast forward 30 seconds)
- 123 displays a numeric keypad to enter the CH #
- REC – record options
- Start this program from the beginning
- Tune last channel
- EPG – TV Guide
- CC – Closed Captioning, quick press to turn on/off, long press the center circle button for 2 seconds to choose a different font size

### **Remote arrow down to display more content:**

- What's On
- Trending programs
- Last 10 Channels Tuned
- Your Recordings

## How to See Your 10 Last Watched Channels

While watching a program, press the circle remote button and scroll down a few rows to display the screen showing your last watched channels.

## How to Record

1. You can record the program you are watching live, as described above. You can record one episode or a series.
2. From the TV Guide, you can schedule to record a future program or go back in the TV Guide up to 24 hours to watch or record a program.

**NOTE:** Recordings are auto deleted in 7 days. You have 112 hours of recording space.

## Settings

From the Main Menu, select Settings to display these options.

### Create Favorite Channel Lists

In Settings, create as many favorite channel lists as you want.

### How to See Your Favorite Channels Lists

#### In the Vertical Channel List

Choose between seeing all channels and your favorite lists from the vertical channel list. Press the remote left arrow to display all channels in a vertical list on the left side of the screen, then press the remote right arrow to toggle through your favorite lists.

### Changing Your Favorite Lists

When viewing all channels in the vertical Guide, press and hold the center circle remote button to display options. Here, you can add this channel to a favorite list.

When viewing a favorite channel list in the vertical Guide, long press for 2 seconds the center circle remote button to display options. Here, you can remove this channel from your favorite list.

## **Advanced Settings to Change TV Guide View**

From the Settings menu, select "Advanced" then choose "Guide Type". "Classic" is the default grid style guide, and "New" has the larger fonts and channel logos.